

# REPLACEMENT PARTS LIST

Key	Qty	Description
1	1	KIT, TOP LID
2	1	TEMPERATURE GAUGE
3	1	BEZEL, F/ TEMPERATURE GAUGE
4	1	KIT, LOGO PLATE F/ LID
5	1	KIT, HANDLE, F/ LID
6	1	KIT, TOP LID HINGE PINS (SET OF 2)
7	1	KIT, REAR PANEL, TOP LID
8	1	FIREBOWL
9	1	KIT, HEAT SHIELD, F/ FIREBOWL
10	1	KIT, GREASE TRAY SUPPORT
11	1	UPPER REFLECTOR
12	1	VAPORIZER CONE
13	1	KIT, ELEMENT
14	1	POWER CONTROLLER
15	1	LED LIGHT RING
16	1	KIT, CONTROL PANEL
17	1	KIT, BEZEL F/ CONTROL KNOB
18	1	COVER, F/ CONTROLLER
19	1	KIT, BOTTOM SKIRT, CONTROL PANEL
20	1	CONTROL KNOB
21	1	WARMING RACK
22	1	GREASE TRAY
23	1	COOKING GRATE
24	1	EMITTER, F/ COOKING GRATE
25	1	LEFT SIDE SHELF, FIXED
26	2	KIT, FOLDING SHELF
27	1	KIT, FRONT BOTTOM SKIRT, FIXED LEFT SHELF
28	1	KIT, REAR BOTTOM SKIRT, FIXED LEFT SHELF
29	1	KIT, BOTTOM SKIRT, FOLDING LEFT SHELF
<b>NOT Pictured</b>		
...	1	PRODUCT GUIDE, EUROPE
...	1	HARDWARE PACK
...	1	GRATE CLEANING TOOL
...	4	CAP, F/ SIDE SHELF
...	1	CORD WARP, LEG (SET OF 2)

Key	Qty	Description
30	2	LIFT HANDLE, SIDE SHELF
31	1	RIGHT SIDE SHELF, FIXED
32	1	KIT, FRONT BOTTOM SKIRT, FIXED RIGHT SHELF
33	1	KIT, REAR BOTTOM SKIRT, FIXED RIGHT SHELF
34	1	KIT, BOTTOM SKIRT, FOLDING RIGHT SHELF
35	1	LEG ASSY, TOP LEFT
36	1	LEG ASSY, TOP RIGHT
37	4	LEG CAP
38	1	LEG SUPPORT WIRE, STRAIGHT
39	1	LEFT LEG ASSEMBLY, FRONT
40	1	LEFT LEG ASSEMBLY, REAR
41	1	RIGHT LEG ASSEMBLY, FRONT
42	1	RIGHT LEG ASSEMBLY, REAR
43	2	CASTER, LOCKING
44	2	CASTER, NON-LOCKING
45	1	FRONT PANEL
46	1	LEFT CAP, FRONT PANEL
47	1	RIGHT CAP, FRONT PANEL
48	1	LEFT PANEL, F/ CART
49	1	RIGHT PANEL, F/ CART
50	1	LEFT CAP, SIDE PANEL
51	1	RIGHT CAP, SIDE PANEL
52	1	CART SUPPORT, CURVED
53	1	BOTTOM SHELF

**NOTE:** Some grill parts shown in the assembly steps may differ slightly in appearance from those on your particular grill model. However, the method of assembly remains the same.

# REPLACEMENT PARTS DIAGRAM

